



1

Push the jaws of the Kro-Clip (with the tail pointing towards the back of the tile) onto the edge of the tile and hammer firmly home.

2

Hammer a nail half way into the rafter (or, as in the picture shown, a hip batten). The fixing point must be located above the clip position, and the distance between the fixing point and the clip must be kept as short as possible.

3

Wrap the tail several times around the nailed fixing point ensuring that the wire is pulled tight between the fixing point and the clip. Hammer the fixing point nail home to secure the tail.