

Protecting Membrane In High Foot Traffic Areas (Decks)

IMPORTANT – THE ONE-PIECE EPDM MEMBRANE IS NOT DESIGNED AS A FINAL WALKING SURFACE AND SHOULD BE PROTECTED FROM EXCESSIVE FOOT TRAFFIC. THE FOLLOWING ARE OPTIONS TO BE CONSIDERED:

Covering With Rubber4Roofs Walkway Pads

Walkway Pads (Peel & Stick) are 30" x 30" skid resistant, molded EPDM pads that can be adhered to the membrane in much the same manner as laying tile:

Clean the membrane if necessary with *Membrane Cleaner* if it is heavily soiled.

Lay the pad in place and mark the area where the membrane will contact the tape. Leave 1/4" gap between pads for drainage.

Remove the walkway pad and apply Rubber *Primer* to the area where the pad will contact the membrane using a *Scrub Pad or roller*.

Peel the backing paper from the pad and place the pad into position. Apply heavy hand pressure or use a linoleum roller to insure the tape is secure to the membrane.

