


Refurbishment Weep Vent

CODE G952



Description

The G952 Refurbishment Weep Vent is designed to provide cavity wall ventilation to existing walls to solve the problem of missing or inadequate ventilation. It is particularly useful in rendered wall constructions where it is notoriously difficult to use traditional built in weep vents.

Quick and easy to install, the Refurbishment Weep Vent is available in a variety of colours to suit most common brick, stone and render finishes.

Features

- Installed in a 25mm diameter drilled hole.
- Louvred chevron grill to help protect against wind driven rain & insect ingress.
- The external flange covers any damage to the substrate caused by the drilling.
- Drip rib ensures clean moisture run off.
- Tube ribs ensure easy lead in to the hole and help retain the vent in position.

Packing Details

50 per box

Weight

0.53kg per box

Material

Polypropylene

Colours

Terracotta, Buff, Black, Blue/Black, Brown, Clear, Grey, White

Manufacturing Process

Injection Moulded

Free Airflow

260mm² per G952

References

BSI: BS5250
 BSI: BS5628
 BSI: BS8000
 Building Regulations 2000: 5.5
 Scottish Building Regulations 2007: 3.10.6
 NHBC: Good Practice guide
 NHBC: Standards 6.1 D6
 NHBC: Standards 6.2 D4

MANTHORPE BUILDING PRODUCTS LTD
 MANTHORPE HOUSE
 BRITTAIN DRIVE
 CODNOR GATE BUSINESS PARK
 RIPLEY
 DERBYSHIRE DE5 3ND

TEL: 01773 303 000
 FAX: 01773 303 300
 EMAIL: customercare@manthorpebp.co.uk
 WEB
www.manthorpebp.co.uk

DRN B.H. Date 19.06.19

The company maintains a policy of continuous development of its product range and reserves the right to amend the specification without notice.

DRG No




MBP 8290
 (Page 1 of 2)

Issue

B

Refurbishment Weep Vent

CODE G952



Fitting Instructions

Preparation

Mark out the locations for the vents and drill a 25mm diameter hole through the external leaf of the wall into the cavity at a slight upward angle at these points. Ensure that the hole is clear and free of debris before proceeding.

Installation

Align the tube with the hole, making sure to have the chevrons of the front grill pointing upward and the flat edge of the drip feature horizontal, running parallel with the run of the wall. Push the vent firmly into the hole using the palm of your hand until the back face of the flange sits flush against the substrate. As the ribs along the length of the tube grip to hold the product in position it may require more force to push the vent into the hole, it is acceptable to gently tap the vent into position using a rubber mallet.

Requirements

The vents can be positioned at high or low level to suit the required detail, and should be placed at both high and low level to achieve a cross flow ventilated cavity if required. To suit the following requirements:

- NHBC Standards 2008 - 650mm² free airflow every 1.2m - Space the G952 at 480mm centres.
- Scottish Building Regulations 2007 - 300mm² free airflow every 1.2m - Space the G952 at 1m centres.

MANTHORPE BUILDING PRODUCTS LTD
 MANTHORPE HOUSE
 BRITAIN DRIVE
 CODNOR GATE BUSINESS PARK
 RIPLEY
 DERBYSHIRE DE5 3ND

TEL: 01773 303 000
 FAX: 01773 303 300
 EMAIL:
 customercare@manthorpebp.co.uk
 WEB
 www.manthorpebp.co.uk

DRN B.H. Date 19.06.19

The company maintains a policy of continuous development of its product range and reserves the right to amend the specification without notice.

DRG No

MBP 8290
 (Page 2 of 2)

Issue

B