




IMPORTANT NOTE:

HOOK BOLT IS THREADED THROUGH FROM INSIDE OF THE ASPIRATOR NOT FROM THE OUTSIDE AS SHOWN IN THE INSTRUCTIONS

**BREWER
COWLS**

Brewer Turbo Strap and Leg Kit



1. Screw the wing nuts slightly on to the threads so they do not come undone.
2. Pass the hook bolts through the holes in the turbo legs so the legs contact the wing nuts (fig1).
3. Pass the hook bolts through the openings on the supporting frame (wing nuts downwards fig2).
4. Place the unit on the chimney.
5. Tighten up the wing nuts so the unit is centred on the chimney.
6. Bend the legs down the outside face of the chimney.
7. Pass the stainless steel band around the legs.
8. Position the stainless steel band approximately 50mm (2") above the lower edge of the legs.
9. Tighten the stainless steel band with a flat bladed screwdriver and bend the bottom of legs back upwards over the stainless steel band. Trim the legs if necessary (fig3).

Brewer Metalcraft Limited, Units C&D, Ford Lane Industrial Estate, Arundel, West Sussex, BN18 0DF
TEL 01243 539639 FAX 01243 533184 Email sales@brewercowls.co.uk www.brewercowls.co.uk



Figure 1: Thread hook bolt through Aspirotor and then add leg bolt hook.